

KK550CU1S COMPRESSOR

TECHNICAL SPECIFICATION



HUANGSHI DONPER COMPRESSOR CO., LTD.

2023.12

INDEX

	Page
1. Compressor Type	2
2. Performance Data	2
3. Running Condition	2
4. Compressor Mechanical Information	3
5. Compressor Shape	3
6. Wiring Diagram	3
7. Fixing of mounting bracket and cabinet base	4
8. Starting relay and overload protector	5
9. Capacitor	6
10. Components drawing	6
11. Delivery State	7
12. Package、Storage and Transportation	7
13. Technical Items	8

1. Compressor Type

Compressor model	KK550CU1S
Rated voltage/frequency	220-240V~50Hz
Refrigerant	R290
Application	Low back pressure (LBP)
Cooling method	Fan Cooling
Start torque	High starting torque (HST)
Control device	Capillary tube
Motor type	CSR
Running capacitor	6μF
Starting capacitor	50μF

2. Performance Data

Displacement	Net Wt.	Oil Charge	Cooling Capacity(≥95%)										COP(≥95%)		Input power (≤115%)	Current (≤110%)	
			ASHRAE										CECO MAF	ASH RAE	CECO MAF	ASHRAE	ASHRAE
			-35	-30	-25	-23.3	-20	-15	-10	-5	0	-25	-23.3	-25	-23.3	-23.3	
cm³	kg	ml	w	w	w	w	w	w	w	w	w	w	w/w	w/w	w	A	
11.6	11.2±0.4	320±10	339	438	547	550	686	847	1025	1238	1469	451	1.50	1.28	367	1.9	

Note: These datas come from the test without a PTC relay

Testing condition:

Test conditions	LBP	
	ASHRAE	CECOMAF
Evaporating Temp.	-23.3°C	-25°C
Ambient Temp.	+32.2°C	+32°C
Condensing Temp.	+54.4°C	+55°C
Suction Temp.	+32.2°C	+32°C
Subcooling Temp.	+32.2°C	+55°C

3. Running Condition


Ambient temp.	0~43°C
Evaporating temp.	-35~-15°C
Voltage range	187~254V
Max. condensing temp.	65°C
Max. winding temp.	130°C
Max. shell temp.	110°C
Max. discharge temp.	130°C
Start voltage	187V [0.8/0.8MPa(abs)]

Shell min. resistance to pressure	35bar
-----------------------------------	-------

4. Compressor Mechanical Information

Oil type	POE oil
Viscosity	28.8~35.2mm ² /s(40°C)
Oil charged	320±10ml
Diameter of suction tube (I.D.)	Φ 6.2±0.1mm
Diameter of discharge tube(I.D.)	Φ 4.95±0.1mm
Diameter of process tube (I.D.)	Φ 6.2±0.1mm
Wall thickness of suction tube	1.00±0.1mm
Wall thickness of discharge tube	1.00±0.1mm
Wall thickness of process tube	1.00±0.1mm
Material of suction tube, process tube and discharge tube	Copper tube
Compressor noise	≤54dB(A)
Vibration	≤1.8m/s ²
Protecting gas	-0.06~-0.02MPa

5. Compressor Shape




Caution:Suction tube and process tube can not be exchanged

Unmarked tolerance: ± 5mm

Unmarked Angle: ± 10°

6. Wiring Diagram


Rank of insulation	B
Electric safe	GB4706.17/IEC60335-2-34



Note: Each of the starting relay、the overload protector、the capacitor、the relay cover and the earth bolt is separately provided by our company.

7. Fixing of mounting bracket and cabinet base

- 1、Hexagon nut
- 2、Spring washer
- 3、Flat washer
- 4、Compressor mounting bracket
- 5、Rubber grommet
- 6、Sleeve
- 7、Cabinet base
- 8、Screw



Note: Equipment assembly is all provided by our company. Above is just for reference, details can refer to delivery state.


8. Starting relay and overload protector

8.1 Starting relay

Model		QL2-6.8/QL2-6.80	
Supplier		Hangzhou Star shuaier Electric Appliance Co.,Ltd.	Changshu Tianyin Electromechanical Co.,Ltd.
Max current	A	6.8	
Min current	A	5.75	

Assembly force $\leq 100\text{N}$ Disassembly force $\geq 25\text{N}$

Flammability: Anti-flammability




8.2 Overload protector

Model		B99-135/DRB B99-135	
Supplier		Changshu Tianyin Electromechanical Co.,Ltd.	Hangzhou Star shuaier Electric Appliance Co.,Ltd.
Max.T.C Amp.(25°C)	A	9.9	
Trip time	S	6~16	
Reset time	S	10~80	
Open temp.	$\pm 5^{\circ}\text{C}$	135	
Close temp.	$\pm 9^{\circ}\text{C}$	61	

Assembly force $\leq 80\text{N}$ Disassembly force $\geq 12.5\text{N}$

Flammability: Anti-flammability




9. Capacitor

Type		Starting capacitor	Running capacitor
Model	μF	50	6
Rated voltage	V.AC	330	450
Supplier	Ningguo Yuhua Electrical Product CO.,LTD		
	Shanghai haoyue Electronics CO.,LTD		
	Anhui Tongfeng Electronics CO.,LTD		
	Anhui Feida Electrical Technology CO.,LTD		


10. Components drawing

(1) Sleeve




Unmarked tolerance $\pm 0.2\text{mm}$

(2) Relaying cover assembly



Unmarked tolerance $\pm 1\text{mm}$

(3) Rubber grommet



Unmarked tolerance $\pm 0.5\text{mm}$

11. Delivery State

No.	Name	Model	Quantity	Code
1	Compressor	KK550CU1S	1pcs	
2	Rubber plug	Φ6.4	1pcs	
		Φ8.2	2pcs	
3	Rubber grommet	H	4 pcs	
4	Starting relay	QL2-6.8/QL2-6.80	1 pcs	Changshu Tianyin Electromechanical Co.,Ltd.
				Hangzhou Star shuaier Electric Appliance Co.,Ltd.
5	Overload protector	B99-135	1 pcs	Changshu Tianyin Electromechanical Co.,Ltd.
		DRB B99-135		Hangzhou Star shuaier Electric Appliance Co.,Ltd.
6	Comb capacitor	50+6μF	1pcs	
7	Spring for overload protector	QS08-06A	1pcs	
8	Relaying cover	S2	1 pcs	
9	Spring for cover	QS08-05H	1pcs	
10	Anchor bolt assembly	M6×30	4pcs	
11	Earth bolt	QET.1-24C	1pcs	
12	Nut	QET-27	4pcs	
13	Sleeve	QET-04	4pcs	

Notes:1.Except spring for overload protector and rubber plug, the other electrical parts and equipment assembly are supplied separately, not installed on the compressor.

2.All electrical parts and equipment assembly according to “Delivery state”are all provided by our company.

12. Package、Storage and Transportation

Package type	unrecyclable
Quantity	60pcs/box
Transportation	By sea
Storage	Max. 2 layers
Cross Weight Kg	707±32
Net Weight Kg	672±32
Volume m ³	0.99
Dimension: length×width×height cm	103×89×108

Main components	Wooden supporter、upper wooden cover、foam divider、plastic sheet、cardboard cover、rain-proof cover、wrapping
Movement	Keep the compressor in normal or vertical position
Trans. test requirement	No allowable compressor's damage and performance loss.

13. Technical Items

- (1)、Don't take off the rubber plugs before using and installing compressor to prevent dust and moisture.
- (2)、Don't turn down or incline the compressor during storage, transportation or installation and avoid vibration and shock.
- (3)、The compressor must be kept horizontally during running, the inclination angle must be less than 5°.
- (4)、A special polyester oil is charged in the R290 compressor and the charging volume has been optimized by DONPER. Don't pour out or add any refrigerant oil.
- (5)、The interval of compressor operation must be more than 4 minutes in order to obtain a pressure balance in the systems.
- (6)、Don't start or run in the case of vacuum or charge high voltage in the compressor. The compressor cannot be used to vacuumize the refrigeration system.
- (7)、The design of refrigeration system must be suitable to insure the oil could flow back to compressor.
- (8)、The maximum ambient temperature of the compressor operation is 43°C. When continuously operating under the maximum ambient temperature 43°C, the condensing pressure and the peak pressure should not exceed as showing in the following table.

Refrigerant	R290
Max. condensing pressure	2.01MPa
Peak	2.44MPa

- (9)、Widen the evaporating Temp. range of the compressor should be approved by DONPER.
- (10)、Compressor should be stored in a dry place.
- (11)、Compressor accessories (eg: starting relay, overload protector etc.) are put in the accessories box instead of fixing on the compressor.
- (12)、The inventory period of the compressor after leaving the factory should not exceed 6 months. If it exceeds 6 months, please check if the protective gas inside the compressor is under negative pressure.
- (13)、It's necessary to keep the compressor without rubber plug as short time as possible (max time 10 min).
- (14)、R290 systems require a filter with drying agent which suitable for R290 refrigerant
- (15)、The vacuum pump and the charging system must only be dedicated to R290.

- (16)、The refrigeration system should minimize the content of chlorine and moisture, and must be free of paraffin and silicon oil.
- (17)、The organic substance non-compatible with R290 cannot be used in the refrigeration system.